

AMERICAN CHANGER & HOFFMAN MINT

We Are Changing the IndustrySM



1400 N. W. 65th Place, Fort Lauderdale, Florida 33309
T: (+1) 954-917-3009 F: (+1) 954-917-3079
www.americanchanger.com www.hoffmanmint.com



New Marquee Installation Guide (Double Board)

1. Turn off the machine. Unplug the machine from the outlet and disconnect the original marquee from main board.



Marquee will be connected here.

2. Remove the original marquee from the cabinet. Four screws hold it to the top of the cabinet. Be sure to pull the marquee harness completely through the hole in the top of the cabinet when removing the marquee.
3. Remove new marquee from plastic wrap. Run marquee wire through the hole in the top of the cabinet and screw marquee in place.

4. A small power supply was shipped with the marquee. Connect the power supply to the board.



Marquee Power Supply



The power supply will connect here.

5. Connect the power supply that was connected to the main board in the previous step to the marquee harness. Tie up excess wire in the same fashion as the original marquee. Finally plug the machine back into the outlet and turn on the board.